

Wet/Dry Shaver												
Triple Blade												
	ES8163	ES8162	ES8161	ES8093	ES8092	ES8044	ES8043	ES7038	ES7036	ES6003	ES6002	
	Outer Foil	WES9065Y			WES9063Y			WES9085Y				
	Inner Blade	WES9066Y			WES9064Y			WES9064Y				
Foil and Blade Set	WES9011Y			—			WES9012Y					
Wet/Dry Shaver								Travel Shaver				
Triple Blade			Double Blade					Single Blade				
	ES8018	ES8017		ES4033	ES4032	ES4027	ES4025		ES3042	ES4815	ES3830	
	Outer Foil	WES9077Y		Outer Foil	WES9837Y				Outer Foil	WES9941Y	WES9837Y	WES9941Y
	Inner Blade	WES9074Y		Inner Blade	WES9850Y				Inner Blade	WES9942Y	WES9850Y	WES9942Y
Foil and Blade Set	WES9007Y	Foil and Blade Set	WES9839Y			Foil and Blade Set	—	WES9839Y	—			
Card-Sized Shaver		Ladies Shaver		Facial Trimmer			Manicure Care		Pedicure Care			
Single Blade												
	ES518	ES2235	ES2211	ES2113P	ES2113A	ES2401	ES2502					
	Outer Foil	WES9933Y	WES9775Y	Downy Hair Blade	WES9275PY	WES9275AY	WES0171Y	WES0191Y				
	Inner Blade	WES9932Y	WES9752Y	Eyebrow Blade	WES9257PY	WES9257AY						
Foil and Blade Set	—	—	—	—	—	—	—					
Hair Clipper			Beard/Hair Trimmer									
												
ER508	ER510	ER240	ER230	ER221	ER220	ER217	ER206					
WER9102Y		WER9601Y	WER961Y	ER965	WER9602Y		WER9601Y					
Professional Hair Clipper												
												
ES291	ER160	ER154	ER149	ER148	ER145	ER121						
WES9273Y	WER9792Y		WER9712Y	WER9711Y	WER9181Y	WER935Y						

Shaver		Model No.	Accessory	
Wet/Dry Shaver	Triple Blade	ES8080	Outer Foil	WES9061Y
		ES8068, ES8066, ES7006, ES7003, ES883, ES882, ES766, ES765, ES762	Inner Blade	WES9074Y
			Outer Foil	WES9075Y
		ES8026, ES7017	Inner Blade	WES9074Y
			Outer Foil	WES9077Y
		ES8003	Inner Blade	WES9074Y
	Outer Foil		WES9081Y	
	ES7027, ES7026, ES7016	Inner Blade	WES9080Y	
		Outer Foil	WES9077Y	
		Foil and Blade Set	WES9007Y	
	Double Blade	ES761	Outer Foil	WES9093Y
			Inner Blade	WES9850Y
		ES4001, ES723	Outer Foil	WES9837Y
			Inner Blade	WES9850Y
		ES744, ES743, ES742, ES705, ES704, ES703, ES702	Outer Foil	WES9861Y
Inner Blade			WES9870Y	
ES727, ES726, ES725, ES722, ES719, ES718	Outer Foil	WES9835Y		
	Inner Blade	WES9850Y		
Single Blade	ES3041, ES3001, ES876, ES366, ES365	Outer Foil	WES9941Y	
		Inner Blade	WES9942Y	
	ES867, ES865	Outer Foil	WES9961Y	
		Inner Blade	WES9972Y	
Dry Shaver	ES375, ES372	Outer Foil	WES9973Y	
		Inner Blade	WES9972Y	
	ES301	Outer Foil	WES9961Y	
		Inner Blade	WES9972Y	
Travel Shaver	ES843, ES815	Outer Foil	WES9941Y	
		Inner Blade	WES9942Y	
	ES805	Outer Foil	WES9837Y	
		Inner Blade	WES9850Y	
		Foil and Blade Set	WES9839Y	
	ES804	Outer Foil	WES9961Y	
Inner Blade		WES9972Y		
Card-Sized Shaver	ES514	Outer Foil	WES9933Y	
		Inner Blade	WES9932Y	
Ladies Shaver	ES209, ES207	Outer Foil	WES9775Y	
		Inner Blade	WES9752Y	
	ES206, ES204, ES201, ES179, ES177, ES173	Outer Foil	WES9753Y	
		Inner Blade	WES9752Y	
Manicure System	ES103	File Set	ES017	

Trimmer		Model No.	Accessory	
Hair Clipper		ER507	WER936Y	
Beard/Hair Trimmer	ER398, ER201	WER9453Y		
		Trimmer Blade	WER966Y	
		Outer Foil	WES9786Y	
		Inner Blade	WES9787Y	
	ER216, ER215	WER966Y		
		WER963Y		
		WER964Y		
		WER9193Y		
Professional Hair Clipper	ER214, ER213	ES9264		
		WER9130Y		
	ER211, ER210	WER9792Y		
		WER9712Y		
	ER205, ER204, ER203	WER9711Y		
		WER9130Y		
	ER202, ER200	ER9199		
		ES290		
Professional Hair Clipper	ER721, ER130			
	ER153, ER152			
	ER147			
ER146				
ER141				
ER140				